P.I.T.
Progressive Innovational Technology

EN PRODUCT PASSPORT
USER'S MANUAL

RU ПАСПОРТ ИЗДЕЛИЯ
ИНСТРУКЦИЯ ПОЛЬЗОВАТЕЛЯ

ENGRAVERS, MOZZILE SET 211 PCS
ГРАВЕР, НАБОР НАСАДОК 211 ШТ

PMG150-C

PROGRESSIVE INNOVATIONAL TECHNOLOGY
ПРОГРЕССИВНЫЕ ИННОВАЦИОННЫЕ ТЕХНОЛОГИИ

Поставщик: Ханай Юнджинь Лэнджо Индастриал Со., Лтд.
Адрес: Индустриальная зона Лэнджо, Город Юнджинь, Ухэ, Ухай, Экономико-Технологическая Зона Развития, Хэбэй, Китай
Импортер: ООО "Трейдинговая компания "ПОРТ"
Юридический адрес: 614107, г.Пермский край, г.Пермь, ул. Уинская,дом 2, Е
Сделано в КНР/Made in China

www.pit-tools.com

GENERAL SAFETY PRECAUTIONS

1. Always keep the workbench clean. Contaminated workplaces and workbenches increase the risk of accidents.
2. Consider the influence of the environment in which you work. Do not expose the tool to rain. Do not use the tool in damp or flammable environments. Use the tool in well-lit areas. Do not use the tool in the presence of flammable liquids or gases.
3. Protect yourself against electric shock. Avoid physical contact with grounded surfaces (pipes, radiators, stoves, refrigerators).
4. Keep children away. Do not allow children to touch the tool or the extension cord. Do not allow other people to touch the tool or the extension cord. Keep them away from the workplace.
5. Store the tool when not in use. The tool should be stored in a dry, high or locked place out of the reach of children.
6. Do not overload the tool. It will work better and safer at the rated power.
7. Use the right tool for the job. Do not force the tool or attachment to do the job for which it was not designed.
8. Dress appropriately. Do not wear loose clothing or jewelry. They can be caught in moving parts. Rubber gloves and non-slip footwear are recommended when working outdoors. Wear protective hair covering to keep long hair from getting caught in moving parts.
9. Use safety glasses. Also use a face or dust mask if the operation is dusty.
10. Do not abuse the cord. Never carry the tool by the cord or yank it to disconnect it from the socket. Keep the cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.
11. When operating a power tool outdoors, use an appropriate power extension. Use only a power extension for the wire cross-section. Using a cord for the wrong cross-section increases the risk of overheating and burning of the cord.
12. Secure the workpiece. Use clamps or a vise to hold the workpiece. It is safer than using your hand and frees both hands to operate the tool.
13. Do not overreach. Keep your balance and footing at all times. This allows better control of the tool in unexpected situations.
14. Maintain the tool with care. Keep the tool sharp and clean for the best and safest performance. Follow the instructions for lubrication and changing accessories. Inspect the tool cord periodically and if damaged, have it repaired by an authorized service center. Inspect the extension cords periodically and replace them if damaged. Keep the handles dry, clean and free from oil and grease.
15. Disconnect the tool when not in use, before servicing, and when changing accessories, such as blades, bits and cutters.
16. Remove adjusting keys and wrenches. Form the habit of checking to see that keys and adjusting wrenches are removed from the tool before turning it on.
17. Avoid unintentional starting. Do not carry the plugged in tool with your finger on the switch. Make sure the switch is off when plugging in.
18. Use outdoor extension cords. When the tool is used outdoors, use only extension cords intended for outdoor use and so marked.
19. Stay alert. Watch what you are doing. Use common sense. Do not operate the tool when you are tired.
20. Check for damaged parts. Before further use of the tool, a guard or other part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced by an authorized service center unless otherwise indicated elsewhere in this instruction manual. Have defective switches replaced by an authorized service center. Do not use the tool if the switch does not turn it on and off.
21. Warning! The use of any accessory or attachment, other than those recommended in this instruction manual, may present a risk of personal injury. Only accessories that are recommended for use with your tool should be used.
22. Do not attempt to replace the power cord. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
23. Do not use the tool if the switch does not turn it on and off.
24. Warning! The operation of any power tool can result in foreign objects being thrown into your eyes, which can result in severe eye damage. Always wear safety goggles or eye protection with side shields before commencing power tool operation. We recommend Wide Vision Safety Mask for use over eyeglasses or standard safety glasses with side shields.
25. Warning! Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:
- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as face or dust masks that are specially designed to filter out microscopic particles.

INTENDED USE

Mini grinder kit PMG150-C can be used for carrying out minor mechanical work of different profile, drilling holes, deburring, grinding of high speed steel weapons etc. Useful for the home and for professional use in various industries.

EXPLANATION OF P.I.T. TRADEMARK

P.I.T. Progressive International Technology

Currently, 20 kinds of mechanical and electrical products are produced under the P.I.T. trademark. In order of sales, electric rotor grinders occupy one of the leading positions.

Each kind and number in the designation of the P.I.T. rotary grinder has the meaning:

OPERATION PRINCIPLE

Electrometer creates a rotating force for the accessory, fixed in the clamping chuck. The rotation speed of the motor itself is normal, so the gearbox is not used in the tool to reduce the rotation speed.

PRODUCT SPECIFICATIONS

	PMG150-C
Rated voltage:	220 V
Rated frequency:	50 Hz
Collet chuck:	3.4-3.2 mm
No-load speed:	10,000-33,000 rpm
Rated capacity:	150 W
Cable:	0.65 kg

FUNCTIONAL CAPABILITIES AND FEATURES OF THE ELECTRIC MINI-GRINDER

Functional capabilities:
It is used for grinding, engraving, sharpening, deburring, drilling holes in plastic, ceramics, metal and wood. The tool is equipped with a speed controller.

Features:
- Durable motor, accuracy of work;
- Ergonomic design, low weight;
- Smooth start / speed control.

MODEL	SOCKET DISCHARGE	SPEED CONTROLLER	REVERSE ROTATION	SOFT-STARTING KEY
PMG150-C	●	●		

ELECTRIC MINI-GRINDER ASSEMBLY

1. On/Off control
2. Speed control
3. Collet chuck nut
4. Collet (brush) cover

RULES OF OPERATION

ELECTRICAL SAFETY REQUIREMENTS

Before connecting the tool to the power supply, make sure that the parameters of the power supply network, specified on the nameplate of the tool, correspond to the parameters of the power supply network of your apartment, house, workshop, etc. If it is not recommended that the power cord and the tool are used, we do not change, we limit cleaning, painting or wiping. Do not use the tool if the power cord is damaged. Do not touch the power cord with oily hands. Do not pull the power cord to disconnect the tool from the power supply. Do not allow the power cord to come into contact with heated surfaces. Do not allow the power cord to come into contact with sharp edges and corners. Do not allow the power cord to be twisted, bent or crushed. Do not use the tool in the rain. Do not allow the tool to get wet. Do not use the tool in damp rooms. Do not use the tool in the presence of flammable liquids or gases. Do not use the tool if the switch does not turn it on and off. Do not use the tool if the switch does not turn it off. Do not use the tool if the switch does not turn it off. Do not use the tool if the switch does not turn it